

Stainless Steel Double Containment Piping for Diesel, Gasoline, Biofuels and DEF

Design and Installation Guide - May 2023





OmegaFlex





Next Generation of UL971A and UL1369 Stainless Steel Double Containment Piping

ABOVEGROUND, UNDERGROUND, AND MARINA APPLICATIONS TABLE OF CONTENTS

Ab	oveground, Underground, and Marina Applications	
1.	INTRODUCTION	Page 2
2.	LISTINGS AND APPROVALS	Page 3
3.	PRESSURE RATINGS	Page 3
4.	OPERATING TEMPERATURE	Page 3
5.	BEND RADIUS	Page 3
6.	INSPECTION, HANDLING AND STORAGE	Page 3
7.	ASSEMBLY OF DoubleTrac [®] FITTING	Page 4
8.	DISASSEMBLY OF DoubleTrac [®] FITTING	Page 8
9.	INSPECTION OF DoubleTrac® FITTING COMPONENTS	Page 9
10.	TIGHTNESS TESTING OF DoubleTrac® PIPING	Page 11
11.	. DoubleTrac [®] CONTINUOUS MONITORING	Page 12
12.	INSTALLATION OF CHECK VALVE	Page 12
13.	PIPE BURIAL, TRENCHING AND BACKFILL REQUIREMENTS	Page 12
14.	ROUTINE MAINTENANCE AND VISUAL INSPECTIONS	Page 13
15.	CONTACT INFORMATION	Page 13
16.	DoubleTrac® PIPING GUIDE FOR ABOVEGROUND, UNDERGROUND,	
	and MARINA APPLICATIONS	Page 13
17.	RECOMMENDED ENTRY FITTINGS FOR FLAT WALL SUMPS	Page 14
18.	INDOOR/OUTDOOR PIPE CLAMPING AND INSTALLATION	Page 15
19.	MARINA PIPE CLAMPING AND INSTALLATION	Page 15
20.	DoubleTrac® CONTINUOUS MONITORING INSTALLATION INSTRUCTIONS.	Page 16
21.	RIGID ENTRY FITTING ATTACHMENT INSTALLATION INSTRUCTIONS	Page 22
22.	DoubleTrac [®] CHASE PIPE ENTRY FITTING INSTALLATION	Page 24
23.	DoubleTrac [®] LIMITED WARRANTY ABOVEGROUND AND MARINA	Page 26
24.	DoubleTrac [®] LIMITED WARRANTY INSTALLATION FORM	Page 27
25.	. DoubleTrac [®] LIMITED WARRANTY UNDERGROUND	Page 29



DoubleTrac[®] Aboveground, Underground and Marina Piping System

SECTION 1.0 – INTRODUCTION

This manual provides the installer with general instructions for the design and installation of aboveground, underground, and marina fuel piping systems using DoubleTrac[®] petroleum piping system with built-in secondary containment.

Other components of the piping system have their own individual installation instructions provided by the equipment manufacturer. The installation instructions provided by all component manufacturers must be followed for the aboveground, underground and marina petroleum piping system to operate safely as designed.

The OmegaFlex DoubleTrac[®] piping system must only be installed or serviced by a qualified installer who has been trained through the DoubleTrac[®] Petroleum Piping Systems Installation Training Program. The use of non-trained personnel or any deviations from these written procedures could result in damage or leakage of the system and void the product warranty. Contact OmegaFlex Customer Service for more information at 800-355-1039.

These instructions must be used in conjunction with federal and state regulations for aboveground, underground, and marina bulk petroleum storage and piping, which must be followed.

All aboveground, underground, and marina fuel piping systems must be installed in accordance with recognized engineering practices.

At the completion of work this installation manual must be given to the site operator or owner.

A CAUTION

If the DoubleTrac[®] system is improperly installed, the contents of the piping may leak and possibly cause personal injury or damage to the environment. The instructions in this manual and applicable local codes must be strictly followed.

Overview

DoubleTrac's[®] innovative double wall design includes a primary interior layer of zero-permeation, highly corrosion resistant corrugated stainless steel with an outer EFEP barrier layer bonded to a Nylon 12 protective layer. The unmatched strength of stainless steel combined with the superior chemical resistance of EFEP in the secondary barrier layer provide a highly durable design utilizing proven materials in the industry. The interstitial space provides continuous monitoring for leak detection making DoubleTrac[®] the industry's most effective zero permeation piping solution. DoubleTrac[®] is suitable for use in marinas, harbors, fuel terminals, fuel oil lines, and emergency generator feed and return lines.



SECTION 2.0 - LISTINGS and APPROVALS

OmegaFlex[®] DoubleTrac[®] piping system has both a primary and secondary containment jacket and is dual listed with UL 1369 and UL971A/ULC S679-17 under file number MH 45578.

UL 1369 titled:

ABOVEGROUND PIPING FOR FLAMMABLE AND COMBUSTIBLE LIQUIDS Pressure System Supply Piping Suction System Supply Piping Tank Vent Piping Stage II Vapor Recovery Piping

UL 971A/ULC S679-17 titled: METALLIC UNDERGROUND FUEL PIPE Pressure System Supply Piping Suction System Supply Piping Tank Vent Piping Stage II Vapor Recovery Piping

SECTION 3.0 - PRESSURE RATINGS

shown in Table 1.

DoubleTrac[®] piping and fittings have a minimum five to

one safety factor from the maximum rated operating pressure for the primary and secondary pipes. The product media must not exceed the maximum

operating pressures indicated for each pipe size

SECTION 4.0-OPERATING TEMPERATURE

Underground: -40°F to 155°F Aboveground: -22°F to 122°F

SECTION 5.0-BEND RADIUS

DoubleTrac[®] piping must never be bent at a radius smaller than the designed bend radius shown in Table 2.

			Table 2		
Pipe	Size	with	Minimum	Bend	Radius

Pipe Size	Minimum Bend Radius
1"	12"
1-1/2"	24"
2"	32"

SECTION 6.0 - INSPECTION, HANDLING and STORAGE

Inspect all piping, fittings, and components when they arrive at the job site. Any piping that has been cut, crushed, or otherwise subjected to physical damage during transportation or storage shall be discarded and never used. The piping and fittings shall be handled in such a manner that will not cause any damage. Keep all components in the original packaging until ready for use. Inspect fittings prior to installation.

The end of the piping must be protected at all times. Extra caps are provided with each shipment.

Pipe Size	O.D. Nom	Weight	Primary Max Operating Pressure	Secondary Max Operating Pressure	Max Vacuum Rating
1"	1.55	0.75 lbs/ft	125 psig	50 psig	29" Hg
1-1/2"	2.30	1.50 lbs/ft	100 psig	50 psig	29" Hg
2"	2.93	2.00 lbs/ft	75 psig	50 psig	29" Hg

Table 1Pipe Size with Maximum Operating Pressure

SECTION 7.0 - ASSEMBLY OF DoubleTrac® FITTING

Tools required for Assembly

- Utility knife with sharp blade •
- Tape measure
- Ratchet •
- Appropriate size allen wrench/allen wrench socket
- **Tubing Cutter**
- Torque Wrench FT/LBS
- OmegaFlex cutting wheel P/N# UGF-E-5272



1. Components



2. To determine the jacket strip length measure back 3" from the end (Figure 7-1).



3. Using the tubing cutter, score the outer jacket approximately three quarters of the way through the jacket circumference. Use extreme caution not to cut or score the stainless corrugated pipe (Figure 7-2).



4. Finish cutting through the outer jacket down to the stainless corrugated pipe using a sharp utility knife (Figure 7-3).



- 5. Carefully cut outer jacket longitudinally with a utility knife for ease of removal. Do not score DoubleTrac® piping (Figure 7-4).



Figure 7-4

Figure 7-1

6. Remove portion of outer jacket (Figure 7-5).



ACAUTION

Inspect the stainless steel pipe for scoring from the tubing cutter. If the stainless steel pipe is damaged, remove the damaged portion and repeat this procedure.

7. DoubleTrac® field attachable fittings (Figure 7-6).



- Figure 7-6
- 8. Loosen cap screws (Figure 7-7).



9. Remove all cap screws (Figure 7-8).



10. Separate the three sections of DoubleTrac® fitting (Figure 7-9).



11. Ensure that the Pusher Ring, Spiral Retaining Ring, and Square profile Rear Seal are installed within the back section of the fitting (Figure 7-10).



Figure 7-10

12. Inspect front section of DoubleTrac[®] fitting. Ensure the fitting does not have any damage to npt threads or front adaptor (Figure 7-11).



Figure 7-11

13. Remove split rings from middle section of DoubleTrac® fitting (Figure 7-12).



14. Ensure outer o-ring is not damaged or torn (Figure 7-13).



15. Ensure inner o-ring is not damaged or torn (Figure 7-14).



Figure 7-14

16. Ensure the beveled/tapered edge of jacket lock faces outward (Figure 7-15).



17. Prepare DoubleTrac[®] piping for final cut. Slide middle section of fitting onto the DoubleTrac® pipe until it bottoms out (Figure 7-16).



Figure 7-16

18. Mark DoubleTrac® piping for final cut. Once the middle section of the fitting has bottomed out on piping, place one split ring half in the corrugation closest to the middle section of the fitting. Ensure split ring drops into first corrugation freely. Place a mark on top of the first two corrugations that are past the split ring (Figure 7-17).



Figure 7-13

19. Remove middle section of DoubleTrac[®] fitting and cut through the corrugated piping using a tubing cutter with a sharp wheel. Cut must be centered in the valley between the two marked corrugations. Use full circular strokes in one direction and tighten roller pressure slightly after each revolution. DO NOT over tighten roller which may flatten tube (Figure 7-18).





A CAUTION

Finishing the cut by bending or twisting may cause an improper seat.

A CAUTION

When making the final cut, do not cut DoubleTrac[®] with a reciprocating saw or hack saw.

20. Slide the back and middle section of the fitting onto the pipe and insert the split rings into the valley of the first corrugation closest to middle section of the fitting (Figure 7-19).



Figure 7-19

21. Slide the back and middle section of the fitting up until the split rings are covered by fitting (Figure 7-20).



Figure 7-20

DoubleTrac[®] field attachable fittings are stainless steel and require the use of an anti-galling agent on the stainless steel bolts. OmegaFlex recommends using Permatex 77124 nickel based anti-seize or equivalent.

Apply constant pressure on backside of fitting to ensure split rings do not come out of seat.

22. Apply an anti-galling agent on the cap screws and insert cap screws into the back section of the fitting. Partially tighten cap screws allowing the fitting to swivel. Swivel DoubleTrac[®] NPT fitting into existing piping (elbow, tee, valve etc.) (Figure 7-21).



Figure 7-21

Do not use any pipe dope or thread sealants on the self-flaring connection. This connection is a metal to metal seat and will not seal properly if pipe dope or thread sealants are used. Sealants are to be used on the NPT Connector to the equipment only. **23.** Tighten all cap screws in an alternating pattern to the torque values listed in Table 3 (Figure 7-22).

	Table 3
Double Irac [®] Recommended Torque Values	DoubleTrac [®] Recommended Torque Values

DoubleTrac [®] Pipe Size	Torque Settings	
1"	30 FT-LBS	
1-1/2" & 2"	50 FT-LBS	



Figure 7-22

SECTION 8.0 - DISASSEMBLY OF DOUBLETRAC® FITTING

1. Loosen the cap screws using a ratchet and the appropriate size hex driver (Figure 8-1).



Figure 8-1

2. Pry off fitting front adaptor using a flat tip screwdriver or flat pry bar (Figure 8-2).

A CAUTION

Use extreme care not to damage fitting or internal o-ring.



3. Remove all cap screws (Figure 8-3).



Figure 8-3

4. Pry the back section of the DoubleTrac[®] fitting using a flat tip screwdriver or flat pry bar (Figure 8-4).



Figure 8-4

5. Once the back section is pried apart from the middle section of DoubleTrac[®] fitting, slide the back section far enough away to allow the middle section of DoubleTrac[®] fitting to slide back exposing the split rings (Figure 8-5).



Figure 8-5

6. With the split rings exposed, remove split rings from DoubleTrac[®] fitting (Figure 8-6).



7. Remove middle section of DoubleTrac[®] (Figure 8-7).

The jacket lock will remain on the outer nylon 12 jacket of the DoubleTrac $^{\tiny (\!R\!)}$ pipe.





8. Using a flat tip screwdriver or flat pry bar, open up jacket lock and remove (Figure 8-8).





9. Remove back section of DoubleTrac[®] fitting (Figure 8-9).



Figure 8-9

SECTION 9.0 - INSPECTION OF DOUBLETRAC® FITTING COMPONENTS

1. Remove DoubleTrac[®] fitting sections and inspect the Nylon 12 outer jacket and AutoFlare of the primary piping for any visible defects (Figure 9-1).



Figure 9-1

2. Prior to reattaching DoubleTrac[®] fitting, thoroughly wipe clean all fitting components (Figure 9-2).



3. Remove outer O-ring on the middle section of DoubleTrac[®] fitting. Inspect O-ring for tears, scuffs, or any visible defect. Replace O-ring as needed (Figure 9-3).



Figure 9-3

4. Remove inner O-ring on the middle section of DoubleTrac[®] fitting. Inspect O-ring for tears, scuffs, or any visible defect. Replace O-ring as needed (Figure 9-4).



Figure 9-4

5. Wipe jacket lock off and inspect for any visible defect (Figure 9-5).



6. Wipe the split rings off and inspect for any visible defect (Figure 9-6).



Figure 9-6

7. Insert jacket lock into the middle section of DoubleTrac[®] fitting (Figure 9-7).



Figure 9-7

Beveled/tapered edge of jacket lock must face outward toward the back section of DoubleTrac[®] fitting.

8. Reinstall inner O-ring. Apply an ample amount of clean bearing grease or lithium grease to inner O-ring (Figure 9-8).



Figure 9-8

9. Reinstall outer O-ring. Apply an ample amount of clean bearing grease or lithium grease to outer O-ring (Figure 9-9).



Figure 9-9

10. Use clean bearing grease or lithium grease to coat the interior surface of DoubleTrac[®] fitting front adaptor (Figure 9-10).



Figure 9-10

11. The DoubleTrac[®] fitting is ready to reinstall, Follow assembly of DoubleTrac[®] fitting instructions beginning in section 7 (Figure 9-11).



Figure 9-11

SECTION 10.0 - TIGHTNESS TESTING OF DOUBLETRAC® PIPING

TIGHTNESS TESTING OF SECONDARY CONTAINMAINT PIPING

For Tightness testing of DoubleTrac[®] piping, the secondary piping (Interstitial Space) must be pressurized with air up to 50 psig for a minimum of 30-minutes. No signs of pressure loss are allowed. For final tightness testing it is recommended that the secondary test is performed for a minimum of 12 hours and shows no sign of pressure loss (Figure 10-1, Figure 10-2 and Figure 10-3).

The site owner/operator must keep a copy of the final test results on file on location.

NOTE: When testing the secondary, the primary is also being tested.

When performing a tightness test, the piping must be completely isolated from the rest of the system.



Figure 10-1



Figure 10-2



Figure 10-3

TIGHTNESS TESTING OF PRIMARY PIPING

The piping system must be isolated from the tanks and subjected to a pipe tightness test on the primary and secondary piping.

For tightness testing of DoubleTrac[®] piping, the primary piping is pressurized with air to a level of 1.5 times the maximum operating pressure of the system. Maintain this pressure for a minimum of one hour, making sure there is no drop in pressure.

NOTE: Before the piping system is backfilled, it must be isolated from the tanks and subjected to a pipe tightness test on the primary and secondary piping.

SECTION 11.0-DOUBLETRAC® CONTINUOUS MONITORING

Continuous interstitial monitoring is required for pipe complying with UL/ULC 1369 Fire Test Clause 12.5 exception 2. Prior to Installation of the DoubleTrac[®] Continuous Monitoring System, Tightness Testing of DoubleTrac[®] must be performed per section 10. Refer to section 20 for DoubleTrac[®] Continuous Monitoring Installation instructions.

SECTION 12.0-INSTALLATION OF CHECK VALVE

Check valves can only be installed on fittings located in landslide sumps. For fittings in sumps located over water install stainless steel plugs

Once all testing has been completed a check valve or stainless steel plug is installed in the secondary port of the DoubleTrac fitting (Figure 12-1).

A CAUTION

Do not overtighten check valve.

If check valves are not installed, then the plug which originally came with the fitting must be installed. Prior to releasing for service, either a plug or check valve must be installed. Failure to do so voids all warranty.



Figure 12-1

SECTION 13.0—PIPE BURIAL, TRENCHING AND BACKFILL REQUIREMENTS

Provide a trench width equal to the pipe outer diameter plus six inches on each side. Separate multiple lines by at least 4 inches. The distance between any piping and the trench excavation walls must be at least 6 inches. For example, an installation of three 2" outer diameter pipes, the trench would be 26" wide and a minimum of 26" deep.

Whenever possible, product lines should be run in a single trench between the tank area and pump dispenser island area. Vent lines between the tank and the structure to which the aboveground vent lines are attached should also be installed in a single trench. Where more than one trench is required, piping should not cross over each other or cross over underground, aboveground and marina tanks.

The trench bottom must be sloped uniformly from the dispensers back to the tanks or sumps at a minimum slope of 1/8 inch per foot and be free of any sharp or protruding hard objects. In pressure systems, slope may not be necessary on supply lines: rather, communication between the interstitial space of the secondary contained pressure supply lines and collection sumps should be maintained so that released product can enter a sump and be visually observed or detected by sensors. The trench bottom must be graded with a minimum of six inches of backfill such as washed sand, or pea gravel.

For backfilling, provide a minimum level of clean backfill between the top of the pipe and the surface as provided in Table 4.

Table 4Minimum Backfill Requirements

Surface Pavement	Min. Depth of Pavement	Min. Level of Clean Backfill
Unpaved	N/A	18"
Asphalt	2"	8"
Reinforced Concrete	4"	4"

A CAUTION

Native back fill materials must never be used.

SECTION 14.0 – ROUTINE MAINTENANCE AND VISUAL INSPECTIONS - PROBLEMS

It is recommended that a visual inspection of all components as well as the inside of all containment sumps be completed at least once per month. Typical monthly inspections include, but are not limited to: • Visual inspection of piping: no visible damage to the outer jacket such as cracks, crushing, kinking, or puncture.

• Visual inspection of all mounting hardware: all hardware must be intact and securely mounted in the original location.

 Visual inspection of DoubleTrac[®] fittings: no visible damage to fittings, no sign of leakage, all vent/test port fittings or bypass hoses must not show signs of crushing, kinking, or puncture.

Fuel leaks collected in containment sumps must be reported immediately and investigated by the site owner. If leakage or damage to the piping system is observed or suspected, OmegaFlex must be notified immediately. All sumps must be kept free of fuel, water and debris. When changing fuel filters at the dispenser, make sure any spilled product is cleaned out of the bottom of the dispenser sump to prevent possible fire hazard.

Ignoring or disabling leak detection alarms can lead to further damage and possible failure of the system.

Failure to remove fuel and liquids from the containment sumps may compromise the performance and integrity of the sump and its associated fittings (entry fittings) and seals over prolonged periods of time.

SECTION 15.0 – OMEGAFLEX INC. CONTACT INFORMATION

OmegaFlex Inc. can be contacted if there are any questions concerning the installation, maintenance or repair of DoubleTrac[®] piping system. Please contact OmegaFlex customer service and 1-800-355-1035 or on the web at www.omegaflex.com or www.doubletrac.net.

SECTION 16.0 – PIPING GUIDE FOR ABOVEGROUND, UNDERGROUND AND MARINA APPLICATIONS

Application Basics

All installations must be performed by a trained operator. Typically each installation is unique and requires some level of review; however, there are some general guidelines that are applicable to all installations. Inspect all piping, fittings and components when they arrive at the job site. Any piping that has been cut, crushed, or otherwise subjected to physical damage during transportation or storage shall be discarded and never used. The piping and fittings must be handled in such a manner that will not cause any unnecessary damage. Keep all components in the original packaging until ready for use. Inspect fittings prior to installation.

CONTINUOUS MONITORING: Continuous interstitial monitoring is required for pipe complying with UL/ULC 1369 Fire Test Clause 12.5 exception 2.

DoubleTrac[®] piping continuous monitoring can be achieved by using DoubleTrac[®] P/N# UGF-CM-KIT. Refer to DoubleTrac[®] Continuous Monitoring Installation Instructions.

SECTION 17.0 - RECOMMENDED ENTRY FITTINGS FOR FLAT WALL SUMPS

OmegaFlex recommends the entry fittings shown in tables 5 and 6 to properly mate up with DoubleTrac® piping. These entry fittings have been evaluated for proper sizing. Other entry fittings may also be used based on compatibility. All entry fittings must meet local, state, and federal regulations for bulk petroleum storage and piping.

	Recommended Entry Fittings for Single Wall Sumps: Flat Wall						
DoubleTrac [®] Pipe Size	O.D. Nom	Bravo Part No.	Diversified Part No.	Chase Pipe Fitting	Omegaflex Part No.	Diversified Products – Fiberglass Rigid Entry Fitting - Flat Wall	
1"	1.55	F-10-OFLX-CR3.5	B 3.5-1.6	UGF-OFDT-B6-1.6	UGF-EF-16	OF PF-FGT-2.5-1.6	
1-1/2"	2.30	F-15-OFLX-CR5	B 3.5-2.4	UGF-OFDT-B6-2.4	UGF-EF-24	OF PF-FGT-4.5-2.3	
2"	2.93	F-20-OFLX-CR5	B 5-3.0	UGF-OFDT-B6-3.0	UGF-EF-32	OF PF-FGT-4.5-3.0	

Table 5	
Recommended Entry Fittings for Single Wall Sumps: Flat Wal	I

Table 6
Recommended Entry Fittings for Double Wall Sumps: Flat Wall

DoubleTrac [®] O.D. Bravo Pipe Size Nom Part No.		Diversified Products Part No.	Diversified Products – Fiberglass Rigid Entry Fitting - Flat Wall	
1" 1.55 F-10-OFLX-D-CR3.5		U8M-1.6	OF PF-FGT-2.5-1.6	
1-1/2"	2.30	F-15-OFLX-D-CR5	U8M-2.4	OF PF-FGT-4.5-2.3

LinkSeal[®] Installation Detail (Figure 17-1).



Figure 17-1

Table 7 **Recommended Link Seal®**

Size	Size LinkSeal [®] No.	
1"	LS-275-OS-316-8	Nitrile Seals
1-1/2"	LS-300-OS-316-6	Nitrile Seals
2"	LS-200-OS-316-9	Nitrile Seals
1"	LS-275-LS-316-8	EPDM UV Seals
1-1/2"	LS-300-LS-316-6	EPDM UV Seals
2"	LS-200-LS-316-9	EPDM UV Seals

SECTION 18.0 – INDOOR/OUTDOOR PIPE CLAMPING AND INSTALLATION

When installed indoor/outdoor, the DoubleTrac[®] piping must be adequately protected from puncture, shear, crush or other physical damage threats, including possible damage from:

- vehicular or pedestrian traffic
- corrosion
- twisting, bending, kinking, chafing, and excessive prolonged movement of the piping
- construction and excavation

When installed along the inside/outside of a structure in an exposed condition, the DoubleTrac[®] piping shall be installed in a location which will not subject the piping to mechanical damage. NOTE: For support and protection, OmegaFlex recommends that inside/outside runs along the side of a building be clamped securely to the wall or other structural component per Table 8. Typical supports are Unistrut conduit hangers, "U" bolts, PVC pipe couplers, or Hosebuns.

Table 8 Clamp Spacing

Maximum Spacing for DoubleTrac [®] Clamping System				
Size	Horizontal	Vertical	Part Number	
1"	6ft max	All sizes of Doubtrac [®] Clamped every floor not to exceed 15ft	UGF-DTSC-16	
1-1/2"	8ft max		UGF-DTSC-24	
2"	10ft max		UGF-DTSC-32	



NOTE: For floating docks piping must be supported evenly along the entire run with clamp spacing a minimum of every 3 feet.

SECTION 19.0 - MARINA PIPE CLAMPING AND INSTALLATION

Fixed Dock

When installing DoubleTrac[®] on a fixed dock, the piping may be run along the side or underneath it. In either case, the routing must be such that it cannot be damaged, crushed, or kinked during normal use of the dock. The piping must be supported evenly along the entire run; supports are required per Table 8. Typical supports are Unistrut conduit hangers, "U" bolts, PVC pipe couplers, or Hosebuns.

Floating Dock

Floating docks are unique and require OmegaFlex Engineering to determine if DoubleTrac[®] can be used along the gangway. In many cases DoubleTrac[®] can be used along the gangway because the tidal surge is not significant enough to cause fatigue or premature failures.

When OmegaFlex Engineering determines DoubleTrac[®] cannot be used along the gangway, the dock to shore connection must be an approved flexible connector.

DoubleTrac[®] can be installed along the length of the floating dock portion. The routing must be such that DoubleTrac[®] cannot be damaged, kinked, or crushed during normal use of the dock. The piping must be supported evenly along the entire run; supports are required a minimum of every 3 feet. Typical supports are dock structure, built-in troughs, Unistrut pipe clamps, "U" bolts, pipe loop hangers, PVC pipe, or Hosebuns.

NOTE: Contact OmegaFlex® Engineering Department for flexible double contained dock connectors at 1-800-355-1039.

A CAUTION

DoubleTrac® field attachable fittings MUST NEVER be submerged under water!

SECTION 20.0 – DOUBLETRAC® CONTINUOUS MONITORING INSTALLATION INSTRUCTIONS

Continuous interstitial monitoring is required for pipe complying with UL/ULC 1369 Fire Test Clause 12.5 exception 2. Prior to Installation of the DoubleTrac[®] Continuous Monitoring System, Tightness Testing of DoubleTrac[®] must be performed per section 10.

UGF-CM-KIT

- (1) Alarm
- (2) Fuel Sensors
- (2) Fuel Sensor Housings
- (2) Secondary Monitoring Shrader Hoses
- (Figure 20-1)



PRODUCT DESCRIPTION

The DoubleTrac[®] Continuous Monitoring System is designed to provide visual and audible alarms whenever a secondary leak is detected in the fuel sensor housing. The system is capable of utilizing a maximum of three weighted float switches and consists of an enclosure weatherproof to an IP54 standard. The weatherproof enclosure contains the visual and audible alarms and the electronic PCB.

The alarm box, featuring the warning devices and test/mute buttons, must be located outside any hazardous zone.

The float sensor(s) can be located in hazardous zones 0,1 or 2 and bears the following certification marking and number:

CML 16ATEX2355X IECEX CML 16.0128X CML 16ATEX2356X IECEX CML 16.0129X

Ex ia IIA T3 Ga -20°C to +40°C

IMPORTANT WARNING NOTES

1. Due to safety critical internal creepage and clearance distances in the control unit, if installed in a location other than a clean and dry environment, the user shall ensure that the control unit is additionally provided with protection having an ingress protection rating of at least IP54 and is maintained throughout the lifetime of the equipment.

2. The float switch incorporates an isolated metal part which could become either charged in use or be a discharge point for charged liquids upon filling or emptying. The float switch shall only be used in applications where static generated via contact liquids are controlled so not to be considered an ignition source.

3. The relay contacts in normal operation shall not switch more than 5Amps, 250V or 100VA max.

4. The alarm box featuring the warning devices and test/mute buttons must not be installed in a hazardous zone or below ground level. The float sensor can be located in zones 0, 1 or 2 with the supplied connecting wire running to the alarm box.

5. The user must ensure that chemicals present in the atmosphere do not affect the performance or degrade the polycarbonate enclosure.

6. Only the correct ATEX/IECEx certified float switches supplied by OmegaFlex[®] can be used with the Tank Alarm.

7. Installation of this equipment and its associated tank, pipe work and fittings must be carried out by a qualified installer.

8. The installation must be carried out in accordance with the requirements of the latest relevant electrical and local authority regulations and standards.

9. DoubeTrac[®] continuous monitoring kit must not be used with any liquids or applications other than those specified. OmegaFlex[®] will not accept warranty claims or liability if it is used for other liquids or applications.

10. DoubleTrac[®] continuous monitoring kit must not be used if damaged.

SPECIFICATIONS

- 115VAC 3-channel alarm.
- IP54 weatherproof enclosure, for outside mounting.
- Each channel can be used as an overfill, low level or bund alarm.
- High power alarm sounder.
- High visibility flashing zenon beacon.
- Test button checks float switches as well as beacon and sounder.
- Continuous Monitoring Alarm will draw approximately 0.44 Amps or 48.4 Watts @110 VAC when in full alarm mode

INSTALLATION INSTRUCTIONS

CONTINUOUS MONITORING ALARM ENCLOSURE

The DoubleTrac[®] Continuous Monitoring Alarm enclosure must be mounted outside any hazardous zone(s). The Fuel Sensors are supplied with 16 feet of 2-core PUR fuel resistant cable and may be extended up to 325 feet.

1. Remove front display lid from alarm box and disconnect ribbon cable. Place the lid somewhere clean and safe (Figure 20-2).



2. Use mounting holes to mount alarm enclosure into position (Figure 20-3).

The DoubleTrac[®] Continuous Monitoring Alarm enclosure must be mounted outside any hazardous zone(s).



Figure 20-3

POWER SUPPLY

The OmegaFlex[®] DoubleTrac[®] Continuous Monitoring Alarm (TA3A.PR.110) is designed to have a continual 120VAC supply fused at a rating of 6 amps max.

1. Remove rubber plug on enclosure and install a liquid tight conduit fitting. Run the main power supply lines into the enclosure.

A WARNING

Ensure power is shut off at the breaker prior to performing any electrical work within the housing enclosure.

2. Connect power supply lines to the "Live Mains" terminals (Figure 20-4).



FUEL SENSOR AND FUEL SENSOR HOUSING INSTALLATION

1. Place Fuel Sensor Housing mounting bracket over housing thread (Figure 20-5).



Figure 20-5

2. Feed Fuel Sensor wire through the bulkhead fitting located on the Fuel Sensor housing cap. Install sensor into the housing and ensure sensor is resting on the bottom of the housing (Figure 20-6).



3. Using a pipe wrench, tighten the Fuel Sensor Housing cap (Figure 20-7).



4. Mount the assembled Fuel Sensor Housing near the DoubleTrac[®] end fitting (Figure 20-8).



Figure 20-8

5. Install Secondary Monitoring Schrader Hose into the housing cap bulkhead fitting. Tighten both housing cap fittings (Figure 20-9).



6. Install and tighten male Schrader valve adapter into the DoubleTrac[®] end fitting (Figure 20-10).



Figure 20-10

7. Attach Fuel Sensor housing hose to the DoubleTrac[®] end fitting (Figure 20-11).



ure 20-7

8. Repeat the Fuel Sensor and Fuel Sensor Housing Installation procedures if an additional fuel sensor is being installed on the opposite end fitting. If only using one fuel sensor then ensure DoubleTrac® secondary plug on opposite end fitting is installed and tightened (Figure 20-12).



9. Feed the Fuel Sensor wire through the bulkhead fitting attached to the Continuous Monitoring Alarm enclosure. Attach both leads of the Fuel Sensor to the corresponding Fuel sensor terminals and tighten the bulkhead fitting (Figure 20-13).



Figure 20-13

NOTE

The Continuous Monitoring Alarm can accommodate up to three Fuel Sensors.

Replace the unused bulkhead fittings with rubber grommets to prevent moisture from entering the enclosure.

DIPSWITCH SETTINGS

1. Switch on the corresponding channel activation dip switch for each Fuel Sensor that is installed (Figure 20-14).

2. Ensure that all float switch settings are switched to the Normal (High Level) setting (Figure 20-14).



Figure 20-14

EXTERNAL RELAY OUTPUTS

The relay contacts are rated at 5Amps, 250V or 100VA max. The relays are a switch only and do not offer a power source for external equipment. The relays are to be used to deactivate the pump control system, however they must not be used to directly switch the electrical load of the pump. If wiring an individual fuel sensor to an individual pump, the Normally Closed or Normally Open terminals of the relay can be utilized to deactivate the pump control system. If using multiple fuel sensors for one pump the output relays must be wired in series using the Normally Closed output terminals. This will ensure a high level alarm triggered by either float switch will deactivate the pump control system.

1. Run the pump control signal wire(s) through a liquid tight conduit fitting and into the DoubleTrac® Continuous Monitoring Enclosure.

2. Connect the signal wire(s) to the internal relay terminals based on the specific sensor/pump configuration. The specific sensor/pump configuration is based on the number of float sensors used and the number of pumps being controlled. Below are typical relay signal wiring schematics based on different sensor/ pump configurations (Figure 20-15 and Figure 20-16).



DoubleTrac[®] Stainless Steel Double Containment Piping Manual for Aboveground, Underground, and Marina Applications

Important Information Follow All Instructions



Figure 20-16

3. Ensure that the pump control signal wires are properly connected to the external pump control system. When properly connected a high level alarm triggered by the float sensors will cause the pump control system to deactivate the pump.

The relays within the Continuous Monitoring Alarm enclosure must not be used to directly switch the electrical load of the pump.

COMPLETION OF INSTALLATION

1. Refit lid to alarm enclosure ensuring that the ribbon cable is reconnected to the main PCB and that the lid seal is in place.

2. Apply the self-adhesive "LEAK" product labels alongside the corresponding channel LED indicator on the front of the alarm housing.

3. Switch on power to the unit. The green "POWER LED" will illuminate to verify power is being supplied.

Overview of completed installation (Figure 20-17).



OPERATION

POWER STATUS

The Power LED will remain illuminated to indicate that there is power to the unit

ALARM CONDITION

When a high-level alarm condition occurs the corresponding channel LED on the Continuous Monitoring Alarm enclosure lid will illuminate and the sounder/beacon and external relay will activate.

FLOAT SWITCH FAULT INDICATION

If any of the channel LEDs flashes repeatedly then this indicates a fault with the fuel sensor (float switch).

ALARM MUTE

Pressing the mute button for 1.5 seconds will silence the sounder when an alarm condition is occurring, the beacon will continue to flash until the alarm condition has been rectified. This will not de-activate any relays. The relays will only be de-activated when float switch returns to its normal position.

If the mute button is not depressed the sounder will silence after 20 minutes leaving the beacon and channel LED on.

The channel LED will remain on until the alarm condition has been rectified (float switch returns to its normal position).

ALARM TEST

To test the Tank Alarm, push and hold the test button on the lid. If the Tank Alarm is functioning correctly the sounder will activate, the beacon will flash and all activated channel LEDs will illuminate.

If any of the channel LEDs flashes repeatedly then this indicates a fault with the float switch.

Figure 20-17



ALARM DIMENSIONS



SECTION 21.0—RIGID ENTRY FITTING ATTACHMENT INSTALLATION INSTRUCTIONS

Components for the Rigid Entry fitting Included with fitting

Rigid Entry Fitting P/N/# UGF-EF-(16, 24, or 32) 60 Grit Sandpaper

Required Accessories

Epoxy Applicator Gun P/N# DF-APGUN-50HD Entry Fitting Cleaner P/N# UGF-EF-CLR 50ML Epoxy Bonder P/N# UGF-EPB-50

Assemble the rigid entry components on the DoubleTrac[®] Pipe entering the sump in the following order (Figure 21-1).

- 1. Threaded body
- 2. Rubber ring
- 3. Plastic ring
- 4. Internal compression nut

*Internal locking ring (only component that does not slide onto pipe)

NOTE: For ease of system installation, DO NOT glue entry fittings to enclosure until the DoubleTrac Piping system has been installed and tightness testing has been completed.

Instructions

- 1. Find the center of your penetration point and drill your hole using a hole saw (see Table 9 for size).
- 2. Rough cut DoubleTrac[®] pipe and prep the end according to section 7.
- 3. Sand the exterior of the DoubleTrac[®] piping that will be contained within the entry fitting. Additionally, sand the inside of the DoubleTrac[®] entry fitting and all the surfaces of the DoubleTrac entry fitting marked with an arrow (Figure 21-1 and Figure 21-2).
- 4. Use the cleaner to clear debris from all the sanded surfaces and the locking ring/threaded body where it makes contact with the mounting surface.
- 5. Assemble rigid entry fitting components on DoubleTrac[®] pipe (see Figure 21-1).
- 6. Assemble DoubleTrac[®] fitting according to Section 7. Ensure the internal locking ring is placed on the ancillary equipment (see Figure 21-2) prior to attaching the DoubeTrac fitting to equipment.



Figure 21-1



Figure 21-2

Table 9Pipe Size/Hole Saw Size

Pipe Size	Hole Saw Size
1"	3-1/2"
1-1/2"	5"
2"	5"

- Prior to gluing DoubleTrac[®] entry fitting to sump wall, tightness testing of secondary containment piping must be performed per section 10.
- Use epoxy bonder cartridge with the applicator gun to cover the serrated surface of the threaded body and internal locking ring and tighten both down to the sump wall (Figure 21-3). For stainless steel sumps there is a Viton gasket to be used in place of the epoxy.
- 9. Tighten rigid entry compression nut onto the threaded body.
- 10. Use epoxy bonder cartridge with the applicator gun to fill all three ports on the threaded body until the ports are visibly full (see Figure 21-4).
- 11. Use any remaining epoxy bonder to "caulk" any seams or contact surfaces.
- 12. Smooth any extra epoxy bonder to create a continuous seal on all seams and contact surfaces.





SECTION 22.0-DOUBLETRAC[®] CHASE PIPE ENTRY FITTING INSTALLATION

Tools and Components:

Required accessories not included with Chase Pipe Entry Fitting (Figure 22-1):

- 1.6" Hole Saw
- 2. 5/16" Nut Driver/Drill
- 3. Part No. UGF-EF-CLR (Chase Pipe Entry Fitting Cleaner)
- 4. Part No. UGF-APGUN-50HD (50ml Heavy Duty Application Gun)
- 5. Part No. UGF-EPB-50 (Epoxy Bonder)
- 6. Sand Paper



Table 10 Chase Pipe Fitting Part Numbers

DoubleTrac [®] Size	Chase Pipe Entry Fitting P/N#
1"	UGF-OFDT-B6-1.6
1-1/2"	UGF-OFDT-B6-2.4
2"	UGF-OFDT-B6-3.0



Figure 22-2

1. Drill through sump wall using a 6" hole saw (Figure 22-3).



2. Sand 1-1/2" around the throughput hole on interior and exterior of sump (Figure 22-4).



Figure 22-4

3. Clean all surfaces using Part No. UGF-EF-CLR and allow to dry (Figure 22-5).



4. Apply an ample amount of Part No. UGF-EPB-50 bonder to the ribbed sealing surface of entry fitting. Ensure enough bonder is used for complete coverage



5. Install the body of the Chase Pipe Entry Fitting through the sump wall (Figure 22-7).



Figure 22-7

6. On the interior of sump thread locking nut onto entry fitting body. Use a pipe wrench to tighten locking nut until snug (Figure 22-8).



Do not overtighten locking nut.

7. Trim face of chase pipe evenly in the valley of a corrugation. Install rubber clamping ring into the valley after the first corrugation. Slide chase pipe into entry fitting until the face of the rubber clamping ring is flush with the face of the chase pipe entry fitting body (Figure 22-9).



Figure 22-9

8. Insert DoubleTrac[®] piping through chase piping to the center point of sump. Insert Chase Pipe Crush Guard into the inside of chase piping (Figure 22-10).



Figure 22-10

9. Ensure Rubber Clamping Ring is aligned under the Rubber Boot band clamp per Assembled Chase Pipe Cross Section View (Figure 22-14). Slide rubber boot over DoubleTrac® piping and ensure the rubber boot bottoms out onto the rubber edge of the entry fitting (Figure 22-11).



10. Use a 5/16" Nut Driver/Drill to tighten the band clamps (Figure 22-12).



Figure 22-12

ACAUTION

Do not overtighten band clamps.

11. Refer to section 7 for instructions on how to install DoubleTrac field attachable fitting (Figure 22-13).



Assembled Chase Pipe Cross Section View (Figure 22-14):



SECTION 23.0 – LIMITED WARRANTY- Aboveground and Marina

PRODUCT	LENGTH OF WARRANTY
DoubleTrac [®] petroleum pipe & fittings	15 years

Omega Flex, Inc. warrants to the purchaser of the DoubleTrac[®] piping system that the products listed above (the "Product") when installed in above ground applications or on fixed or floating docks will be free from defects in material or workmanship for period stated above, as measured from the date of shipment from the Omega Flex facility. This excludes DoubleTrac[®] dock connectors and entry fittings which are covered under a separate warranty.

If upon examination, the Product is shown to have a defect in material or workmanship during the warranty period, Omega Flex, Inc. will, at its option, either repair or replace that part of the Product which is shown to be defective, or issue a credit for the amount of the defective product that may be applied to future orders of the Product.

This limited warranty does not apply:

- If the Product has been subjected to misuse or neglect, has been accidentally or intentionally damaged, or has been altered or modified in any way.
- If the Product has been repaired by anyone who is not a DoubleTrac® authorized service representative.
- If the Product has not been installed in accordance with the DoubleTrac® installation guidelines.
- If the Product has been installed with unauthorized third party components, except those components that are recommended for use with DoubleTrac[®] in the DoubleTrac[®] installation guide.
- To any costs or expenses incurred during investigation, removal or reinstallation of the defective Product, including without limitation any costs or expenses for clean-up, downtime, or lost profits.
- To any damage or impairment of the Product caused by any casualty, including without limitation fires, storms, floods, earthquakes, or acts of God.
- To any workmanship of the installer of the Product.

This limited warranty is conditional upon:

- Receipt of a written warranty claim during the applicable warranty period.
- Installment of the Product by an individual who has received factory authorized training on the installation and proper use of DoubleTrac[®].
- All site and warranty registration forms are completed and received by Omega Flex, Inc. within 30 days of installation.
- All piping and connections are installed with an approved leak detection device in each tank and dispenser sump.
- A sump inspection log or EPA checklist is maintained and provided to Omega Flex, Inc. on request.
- Omega Flex, Inc. receives notice of warranty claim within 24 hours of any known or suspected failure of the Product.

Product can only be returned with prior written approval from Omega Flex, Inc. All returns must be freight prepaid. Omega Flex, Inc. will inspect the alleged defective part, and provide the customer with the results of that inspection whether or not in the reasonable opinion of Omega Flex, Inc., that there exists a defect in material or workmanship. Repair or replacement of any part under this Limited Warranty shall not extend the duration of the warranty with respect to such repaired or replaced part beyond the original stated warranty period.

IMPORTANT

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, AND ALL SUCH OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS LIMITED WARRANTY.

LIMITATION OF LIABILITY

IN NO EVENT WILL OMEGA FLEX INC. BE LIABLE IN ANY WAY FOR (A) ANY CONSEQUENTIAL, SPECIAL, PUNITIVE OR INCIDENTAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING WITHOUT LIMITATION LOST PROFITS, AND WHETHER OR NOT OMEGA FLEX INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR (B) ANY AMOUNTS IN EXCESS OF THE SELLING PRICE OF THE PRODUCT OR ANY PARTS THEROF FOUND TO BE DEFECTIVE.

SECTION 24.0 – LIMITED WARRANTY- Installation Form

Warranty Disclaimer: The DoubleTrac[®] Limited Warranty is only valid if this form is received by the DoubleTrac[®] Customer Service Team within 30 days after installation is complete.

Contractor	Installation Site			
Name	Name			
Address	Address			
Email				
Phone	Installation Date			
Fax	Completion Date			
Installer's State Certification No	- Installer's Training Cort No :			
Pipin	là			
1. What size DoubleTrac® piping was used? (Circle all that apply) 1" 1.5" 2" 2. Installation type (Circle all that apply): Aboveground (Non-Marina) Aboveground (Marina) Underground 3. Was DoubleTrac® piping system continuously monitored? (Circle one) Yes No				
Please circle yes or no to the following:				
4. Was any other piping used other than DoubleTrac [®] ? <i>(Circle One)</i> If so, what kind?	Yes No			
5. What types of fuels are to be stored? (Circle all that apply)	Dis dissel. Other			
Gasoline Gasonol Diesel Ethanol Methanol Fuel Oil 6 Was the site contaminated before installation?	Bio-diesel Other			
If yes: (a) Was the site fully remediated?	Yes No			
(b) Did the site receive clearance from	Voc No			
(c) What is the name of the environmental contractor?	Tes No			
 7. Were all piping and fittings inspected for damage before and after installation? Yes No 8. Was the DoubleTrac® Design and Installation Guide followed? Yes No 9. Were all DoubleTrac® Fittings tightened to proper torque specifications? Yes No 10. Was any direct buried pipe crossed over? Yes No 11. Was the DoubleTrac® Interstitial Space pressure tested? Yes No 12. Was the Secondary Jacket left open to atmosphere after testing? Yes No 				
Pipe Entry Points (please provide)				
Name of Entry Fitting Manufacturer				
All Entry Fitting part numbers				
Dispenser Sumps (please provide)				
Name of Dispenser Sump Manufacturer				
All Dispenser Sump part numbers <i>Circle yes or no:</i> Were sumps inspected for damage before and after Were the instructions followed? Yes No	installation? Yes No			
Tank Sumps (please provide)				
Name of Tank Sump Manufacturer				
All Tank Sump part numbers				
Contractor Signature	Date			
OmegaFlex® 451Creamery Way • Exton PA 19341 • 800.355.1039 (Fax) 610 524 6484 •	www.doubletrac.net			

SECTION 25.0 – LIMITED WARRANTY- Underground

PRODUCT	LENGTH OF WARRANTY
DoubleTrac [®] petroleum pipe & fittings	30 years

Omega Flex, Inc. warrants to the purchaser of the DoubleTrac[®] piping system that the products listed above (the "Product") when installed in underground applications will be free from defects in material or workmanship for period stated above, as measured from the date of shipment from the Omega Flex facility. This excludes DoubleTrac[®] dock connectors and entry fittings which are covered under a separate warranty.

If upon examination, the Product is shown to have a defect in material or workmanship during the warranty period, Omega Flex, Inc. will, at its option, either repair or replace that part of the Product which is shown to be defective, or issue a credit for the amount of the defective product that may be applied to future orders of the Product.

This limited warranty does not apply:

- If the Product has been subjected to misuse or neglect, has been accidentally or intentionally damaged, or has been altered or modified in any way.
- If the Product has been repaired by anyone who is not a DoubleTrac® authorized service representative.
- If the Product has not been installed in accordance with the DoubleTrac[®] installation guidelines.
- If the Product has been installed with unauthorized third party components, except those components that are recommended for use with DoubleTrac[®] in the DoubleTrac[®] installation guide.
- To any costs or expenses incurred during investigation, removal or reinstallation of the defective Product, including without limitation any costs or expenses for clean-up, downtime, or lost profits.
- To any damage or impairment of the Product caused by any casualty, including without limitation fires, storms, floods, earthquakes, or acts of God.
- To any workmanship of the installer of the Product.

This limited warranty is conditional upon:

- Receipt of a written warranty claim during the applicable warranty period.
- Installment of the Product by an individual who has received factory authorized training on the installation and proper use of DoubleTrac®.
- All site and warranty registration forms are completed and received by Omega Flex, Inc. within 30 days of installation.
- All piping and connections are installed with an approved leak detection device in each tank and dispenser sump.
- A sump inspection log or EPA checklist is maintained and provided to Omega Flex, Inc. on request.
- Omega Flex, Inc. receives notice of warranty claim within 24 hours of any known or suspected failure of the Product.

Product can only be returned with prior written approval from Omega Flex, Inc. All returns must be freight prepaid. Omega Flex, Inc. will inspect the alleged defective part, and provide the customer with the results of that inspection whether or not in the reasonable opinion of Omega Flex, Inc., that there exists a defect in material or workmanship. Repair or replacement of any part under this Limited Warranty shall not extend the duration of the warranty with respect to such repaired or replaced part beyond the stated warranty period.

IMPORTANT

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, AND ALL SUCH OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED AND EXCLUDED FROM THIS LIMITED WARRANTY.

LIMITATION OF LIABILITY

IN NO EVENT WILL OMEGA FLEX INC. BE LIABLE IN ANY WAY FOR (A) ANY CONSEQUENTIAL, SPECIAL, PUNITIVE OR INCIDENTAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING WITHOUT LIMITATION LOST PROFITS, AND WHETHER OR NOT OMEGA FLEX INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR (B) ANY AMOUNTS IN EXCESS OF THE SELLING PRICE OF THE PRODUCT OR ANY PARTS THEROF FOUND TO BE DEFECTIVE.



Omega Flex, Inc. 451 Creamery Way, Exton, PA 19341-2509 800-355-1039 • Fax 610-524-6484 www.omegaflex.com ISO 9001 Registered Company

© Omega Flex, Inc. 2023